

Fuel Joint Assembly - Honda Style 5.5HP / 6.5HP (GX160, GX200), Plastic -
20A5000 - PBC2607F1



Rating: Not Rated Yet
Price

\$9.79

[Ask a question about this product](#)

Description

This fuel tank joint assembly is typically found in the Fuel Tank / Engine (Fuel Tank, Recoil Starter, Muffler) section of several part manuals. Commonly used for but not limited to GX110, GX120, GX140, GX160, GX200, GX240, GX270, GX390, and GX440 engines. It is most popularly known for its use in Honda EG1400X A / EG1400XK1 A/A / EG1400XK1 A/B / EG2200X A / EG2200X AR / EG2500XK1 A/A / EG2500XK1 A/B / EG2500XK1 A/C / EG2500XK1 A/D/ EG2500XK1 AC / EG2500XK1 AN / EG3500XK1 A/A / EG3500XK1 A/B / EG3500XK1 A/C / EG3500XK1 AC / EG3500XK1 AN / EG5000X A / EG5000X AR / EG5000XK1 A/A / EG5000XK1 A/B / EG5000XK1 A/C / EG650 A/A / EG650 A/B / EG650 A2 / EN3500 A / EZ1400 A / EZ2500 A / EZ3500 A / EZ2500 A / EZ3500 A/A / EZ5000A / EZ500 A/A / WA20K1 C / WA20K1 D / WA20X C / WA30 C / WA30 D / WA30X C / WB15 C/A / WB20X C / WB20XK1 AC1 / WB20XK1 C1 / WB30X C / WB30X CR / WB30XK1 AC1 / WB30XK1 C1 / WB30XK1 C1 / WD20X C / WD20XK1 AC1 / WD20XK1 AC1/A / WD20XK1 C1 / WD20XK1 C1 / WD30X C / WD30XK1 AC1 / WD30XK1 AC1/A / WD30XK1 C1 / WD30XK1 C1/A / WDP20X A / WDP20XT A / WDP30X A / WDP30XT A / WH15XK1 AC1 / WH15XK1 AC1/A / WH20X CR / WH20XK1 AC1 / WH20XK1 AC1/A / WMP20X A1 / WP20X ACF6 / WP20X ACF6/A / WP30X ACF6 / WP30X ACF6/A / WT20X C / WT20XK2 AC / WT20XK3 AC / WT20XK3 AC/A / WT30X C,

Honda F401

Type A2 / Type AD,

Honda F401K1 A,

Honda F401K2

Type A / Type A2 / Type AC / Type AC/A / Type AC2,

Honda F501

Type A1 / Type A1R / Type A2,

Honda F501K1

Type A1 / Type A2 / Type AC1 / Type AC1/A / Type AC1/B / Type AC2,

Honda FR600

Type A / Type AC/A / Type AC/B / Type AC/C / Type AC/D,

Honda FR650 AC,

Honda FR750

Type A / Type AC/A,

Honda FR800

Type A / Type AC/A / Type AC/B / Type AC/C,

Honda FRC800

Type A / Type AC/A / Type AN,

Honda HS522

Type TA / Type WA,

Honda HS522K1

Type TA / Type TAS / Type WA,

Honda HS522K2

Type TA / Type TAS / Type WA,

Honda HS622

Type TA/A / Type TA/B,

Honda HS724

Type TA / Type TA/A/ Type WA / Type WA/A,

Honda HS80

Type TA / Type TAS/ Type WA / Type WAS,

Honda HS80K1

Type TA / Type TAS/ Type WA / Type WAS,

Honda G100K1 Type QA,

Honda G100K2

Type QA / Type QA2 / Type QD / Type SE3 / Type SMD2 / Type WD12,

Honda GX110

Type DA / Type HX / Type QA / Type QX / Type QXA / Type QXC / Type TX / Type VA / Type VH / Type VX,

Honda GX120K1

Type HT24 / Type HX/A / /Type LJD2/A . Type PX2/A / Type QWA4 /A / Type QX/A / Type R1 / Type RX/A / Type S1/A / Type SG24/A / Type SWX2/A / Type SX/A,

Honda GX120T1

Type QX2 / Type QXS2 / Type SWX2 / Type TX2,

Honda GX120UT1

Type HT2 / Type HTC2 /Type HTF2 / Type HX2 / Type LHQ4 / Type LSB / Type LX4 / Type LXU / Type QA2 / Type QBC4 / Type QH26 / Type QHQ4 / Type QJG2 / Type QMA4 / Type QME4 / Type QW24 / Type QWA4 / Type QX2 / Type QX26 / Type QX4 / Type QX7 / Type QX9 / Type QXC9 / Type QXS2 / Type QXU/ Type SD16 / Type SD4 / Type SG22 / Type SG24 / Type SHQ4 / Type SJD2 / Type SMA7 / Type SWX2 / Type SX2 / Type SX4 / Type SX7 / Type SX9 / Type SXS2 / Type SXS4 / Type TX2 / Type TX26 / Type VEX / Type VEX7 / Type VEX9 / Type VMS4 / Type VX4 / Type VX9 / Type VXU /Type WKS / Type WKT2 / Type WKT4 / Type WKT6 / Type WMA2 / Type WMA3,

Honda GX140

Type HX / Type LX / Type QA / Type QX / Type QXA / Type QXE / Type QXF / Type QXS / Type RH / Type STP / Type STQ / Type STR / Type TX / Type VA / Type VH / Type VX,

Honda GX160K1

Type HB24 / Type HG1 / Type HG12 / Type HG12/A / Type HX / Type HX/A / Type HX/B / Type HX2 / Type HX2/A / Type HX2/B / Type HXE2 / Type HXE2/A / Type HXQ / Type L1 / Type LAX2 / Type LD / Type LX / Type LX/A / Type LX/B / Type PX / Type PX/A / Type PX/B / Type PX2 / Type Q1 / Type QA / Type QA2 / Type QA2/A / Type QA2/B / Type QAX / Type QAX2 / Type QAX2/A / Type QBC2 / Type QBC2/A / Type QBC2/B . Type QBT2 / Type QCB2 / Type QCB2/A / Type QCB2/B / Type QCL / Type QCL/A / Type QCL/B / Type QD / Type QGR2 / Type QGR2/A / Type QGR2/B / Type QGR9 / Type QGR9/A / Type QH2 / Type QH2/A / Type QI2 / Type QI2/A / Type QI2/B / Type QMX2 / Type QMX2/A / Type QMZ2 / Type QS2 / Type QS2/A / Type QS2/B / Type QSC2 / Type QSC9 / Type QSC9/A / Type QWM2 / Type QWX2 / Type QWX2/A / Type QWX2/B / Type QWX3 / Type QX / Type QX/A / Type QX/B / Type QX2 / Type QX2/A / Type QX2/B / Type QX22 / Type QX22/A / Type QX22/B / Type QXC / Type QXC9 / Type QXC9/A / Type QXC9/B / Type QXE / Type QXE2 / Type QXE2/A/ Type QXF / Type QXF2 / Type QXF2/A / Type QXF2/B / Type QXQ Type QXS / Type QXS2 / Type QXS2/A / Type R1 / Type RAC / Type RD / Type RD/A / Type RD/B / Type QXS2/B / Type RFR / Type RFR2 / Type RH / Type RH2 / Type RH2/A / Type RH2/B / Type RHA / Type RHA2 / Type RMG2 / Type RMG2/A / Type RTB2 / Type RTB2/A / Type RX / Type RX/A / Type RX/B / Type RXE2 / Type RXE2/A / Type S1 / Type SAC / Type SD / Type SG24 / Type SM12 / Type SM12/A / Type SM12/B / Type SMW2 / Type SSK2 / Type SSX2 / Type SWX2 / Type SWX2/A / Type SWX2/B / Type SX / Type SX/A / Type TCS2 / Type TCS2/A / Type TCS2/B / Type TX / Type TX/A / Type TX/B / Type TX2 / Type TX2/A / Type TX2/B / Type TXC9 / Type TXC9/A / Type TXC9/B / Type UX / Type VA / Type VA2 / Type VA2/A / Type VEB2 / Type VED2 / Type VED7 / Type VEN2 / Type VEN2/A / Type VEN2/B / Type VG24 / Type VPM5 / Type VPM5/A / Type VPM5/B / Type VW12 / Type VW12/A / Type VW12/B / Type VWA / Type VWA2 / Type VWA2/A / Type VWA2/B / Type VX / Type VX/A / Type VX/B / Type VX2 / Type VX2/A / Type VX2/B / Type VXW / Type VXW1 / Type VXW2 / Type VXW2/A / Type VXW2/B / Type W1 / Type WKT2 / Type WKT2/A / Type WME2,

Honda GX160T1

Type LX2 / Type QA2 / Type QCB2 / Type QGR9 / Type QW24 / Type QWA4 / Type QWW2 / Type QWX2 / Type QX2 / Type QXE2 / Type QXF2 / Type QXS2 / Type SG24 / Type SWX2 / Type TW24 / Type TX2,

Honda GX160U1

Type QXW2 / Type RD4 / Type RTB2 / Type RX4 / Type RXU,

Honda GX160UT1

Type HX2 / Type QAX2 / Type QXC9 / Type QXE5 / Type QXWE / Type RH2 / Type RTB2 / Type RXE2 / Type SXE5 / Type TXC9,

Honda GX200

(Type HX) / (Type HX/A) / (Type HX2) / (Type HX2/A) / (Type HXQ) / (Type LD) / (Type LX2) / (Type LX2/A) / (Type NX) / (Type NX/A) / (Type PX) / (Type PX/A) / (Type PX2) / (Type QAB2) / (Type QD) / (Type QD/A) / (Type QTP2) / (Type QTP2/A) / (Type QX2) / (Type QX2/A) / (Type QXB2) / (Type QXB2/A) / (Type QXC9) / (Type QXC9/A) / (Type QXE2) / (Type QXE2/A) / (Type QXF) / (Type QXF2) / (Type QXQ) / (Type QXS2) / (Type RH2) / (Type RH2/A) / (Type RHA2) / (Type RHA2/A) / (Type RMG2) / (Type RMG2/A) / (Type RX) / (Type RX2) / (Type RX2/A) / (Type SD) / (Type SD/A) / (Type SM12) / (Type SM12/A) / (Type SM22) / (Type SM22/A) / (Type TX) / (Type TX/A) / (Type TX2) / (Type TX2/A) / (Type UX) / (Type VX) / (Type VX/A) / (Type VX2) / (Type VX2/A) / (Type VXP) / (Type VXP/A),

Honda GX200T

Type LX2 / Type QG2 / Type QX2 / Type SM12 / Type TX2 / Type VGS5 / Type VX2 ,

Honda GX200UT

Type HX2 / Type LX2 / Type LX4 / Type LXAU / Type PXU / Type QG2 / Type QH26 / Type QHQ4 / Type QMP4 / Type QX2 / Type QX26 / Type QX4 / Type QX7 / Type QX9 / Type QXB2 / Type QXC9 / Type QXD4 / Type QXD9 / Type QXE2 / Type QXE5 / Type QXE6 / Type QXU,

Honda GX240

Type HA / Type LA / Type PA / Type QA / Type QAC / Type QAE / Type QAE0 / Type RA / Type STP / Type STQ / Type VA,

Honda GX240K1

Type HA / Type HA2 / Type HA2/A / Type HAQ / Type LX2 / Type LX2/A / Type PA / Type PA2 / Type PA2/A / Type PAE / Type PMT2 / Type PMT2/A / Type QA / Type QA2 / Type QA2/A / Type QAB2 / Type QAB2/A / Type QAE / Type QAE2 / Type QAE2/A / Type QAG / Type QAG/A / Type QAG2 / Type QAG2/A / Type QAQ / Type QAR2 / Type QAR2/A / Type QC12 / Type QC12/A / Type QHB2 / Type QMX2 / Type QTC2 / Type QTC2/A / Type QW24 / Type QXC / Type QXC/A / Type QXC9 / Type QXC9/A / Type RA / Type RA2 / Type RA2/A / Type RTB2 / Type RTB2/A / Type SMX2 / Type SMX2/A / Type VA / Type VA2 / Type VA2/A / Type VDG2 / Type VDG2/A / Type WKT2 / Type WKT2/A,

Honda GX240U1

Type QAR2 / Type QE / Type QWB4 / Type QXB7 / Type SXE4,

Honda GX270

Type QWA4 / Type QWH2 / Type SWC4 / Type VM2,

Honda GX340

Type LX / Type QXC,

Honda GX340K1

Type HA / Type HAQ / Type QA / Type QAE / Type QAP / Type QAPE / Type QAQ / Type QNE / Type QNE9 / Type VA,

Honda GX340U1

Type QAE2 / Type QE / Type QME8 / Type QNR6 / Type QXB / Type QXC6 / Type QXC9 / Type SXEB / Type VXE8 / Type VXQ4,

Honda GX340UT2

Type SE2 / Type VXE2/A,

Honda GX390K1

Type HA / Type HA2 / Type HA2/A / Type HAQ / Type HJA / Type HJA2 / Type HJA2/A / Type LX2 / Type LX2/A / Type PA2 / Type PA2/A / Type PAE2 / Type PAE2/A / Type QA / Type QA2 / Type QA2/A / Type QAA2 / Type QAE / Type QAE2 / Type QAE2/A / Type QAQ / Type

QAW / Type QAW/A / Type QC2 / Type QDW9 / Type QDW9/A / Type QH2 / Type QKA2 / Type QKE2 / Type QND / Type QND/A / Type QNE2 / Type QNE2/A / Type QNE9 / Type QNE9/A / Type QNK / Type QNK/A / Type QNR2 / Type QNR2/A / Type QSC2 / Type QWA4 / Type QWA4/A / Type QWC4 / Type QWC4/A / Type QWH2 / Type QWH2/A / Type QWT2 / Type QWT2/A / Type QXC / Type QXC/A / Type QXC9 / Type QXC9/A / Type QXS4 / Type QXS4/A / Type SM32 / Type SM32/A / Type SMX2 / Type SX2 / Type VA / Type VA2 / Type VA2/A / Type VM2 / Type VM2/A / Type VMA2 / Type VMA2/A / Type VME2 / Type VME2/A / Type VXE / Type VXE/A / Type VXE2 / Type VXE2/A / Type VXP7,

Honda GX390T1

Type QA2 / Type QAA2,

Honda GX390U1

Type VXE8 / Type VXQ4,

Honda GX390UT1,

Honda GX390UT2,

Honda GX440IU V2G3,

Maruyama MS330ECH-2,

as well as many other brands of ATVs, UTVs (side-by-side), dirt bikes, scooters, go karts (buggies), and engines with alternative profile names. This fuel joint assembly fits on 3/16" / 1/4" ID fuel line and can work on our 10A9000 and 10A9005 engines.

Fuel Tank Joint Part Code: 14274590

O-Ring Part Code: 0949883

Tube Clips / Clamps Part Code: 0250647

Includes Part Numbers:

- 91353-671-003 O-ring
- 16955-ZE1-000 Fuel Tank Joint
- 95002-02080 Tube Clips or Fuel Line Clamps (Quantity: 2)

Manufacturer Part Numbers:

- Honda Part Numbers: 16955-ZE1-000 "JOINT, FUEL TANK", 91353-671-003 "O-RING, 14mm", 95002-02080 "CLIP, TUBE (B8)" or "CLAMP, TUBE (D8)"
- Rotary Part Number: 10484 Fuel Filter Joint
- Oregon Part Number: 07-393 Fuel Tank Joint
- Maruyama Part Number: 583789 Fuel Tank Joint

Alternative Part Number:

- Honda Part Number: 16955-ZE1-010 "JOINT, FUEL TANK"

Interchangeable Part Numbers / Cross References:

- Stens & Prime Line Part Number: 120-327 Fuel Joint Assembly
- NHC Part Number: 264-9834 Fuel Tank Joint
- Napa Part Number: 7-02395